

The wall needs to follow the outline of the stair...part of the underside of the stair is on the exterior...how can I
1) add/enclose the stair with a angled wall
2) enclose the bottom of the stair with plywood/plaster to match existing?

color in revit is not black but orange...How do I change that back to original?

Level 3
17' - 4"

Level 2
9' - 2"

Level 1
0' - 0"