



dwg file was imported/
linked on level 1 in this revit
file.
(You can still see the grid
number in the level 1 view)



Publish to 3D DWF after
everything's ready.
(Now I can't see the grid
number in the 3D view,
why?)



Open up the 3D DWF file,
all of the dwg info is gone,
why??
(So which steps am I
missing right here?)